



Fitting Instructions

TOWBAR CH3B
For Chrysler Jeep
GRAND CHEROKEE
From March 1996 – Mid 1999

MATERIALS

A	1	Main Crossbar with European facing 94/20/EC – A50-1
B	1	Coupling Packer (10mm)
C	2	Sidearms (Left and Right hand)
D	6	M12 x 40mm Bolts, Lock Washers and Flat Washers (30mm O.D.)
E	6	M12 x 35mm Bolts, Lock Washers and 2 Nuts
CB	2	M16 x 50mm Bolts, Nuts and Lock Washers
Z	1	ZEP35 Electrical Plate (not shown)

FITTING

1. Remove and discard towing eye assembly, re-attaching the rearmost 2 bolts in the existing captive nut strap.
2. Remove the M12 studs located at (X) and loosely attach Sidearms (C) using Bolts (D) with Flat Washers (30mm O.D.)
3. Offer up Crossbar (A) and loosely attach to Sidearms (C) with Bolts (E), fit forward bolts with head on inside to ensure clearance from fuel tank. Finally tighten all bolts.

Note: Alternative towball mountings are provided in the form of a 4 hole faceplate. Use Coupling Packer (B) when lower mountings are used.

Note: This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

