



# Fitting Instructions

TOWBAR DT95A  
For Nissan Vanette / Serena Cargo  
(1995-)

## MATERIALS

|    |    |   |
|----|----|---|
| A  | 1  | Towbar Main Frame   |
| C  | 1  | Side Arm Left Hand  |
| D  | 1  | Side Arm Right Hand   |
| E  | 4  | M10 x 25 x 1.25mm Bolts, 2 Nuts, Lock Washers and 2 Flat Washers (25mmOD) |
| F  | 18 | M10 x 25 x 1.25mm Bolts, Lock Washers and Flat Washers (25mm OD)          |
| G  | 2  | M8 x 35 x 1.25mm Bolts, Lock Washers and Flat Washers (20mm OD)           |
| H  | 2  | Bushes (16mm OD x 20mm long)  |
| CB | 2  | M16 x 50mm Coupling Bolts, Nuts, Lock Washers                             |

## FITTING

1. Temporarily remove rear exhaust mounting.
2. Loosely attach Main Frame (A) to captive nuts provided in rear panel using Bolts (F).
3. Loosely attach Side Arms (C and D) to Main Frame (A) using Bolts (E) and vehicle chassis using Bolts (F).
4. Reverse exhaust mounting and re-attach using longer bolts (G), with bushes (H) between the chassis and exhaust mounting (as shown). Tighten all bolts.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

**Recommended torque settings:** M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

