



Fitting Instructions

TOWBAR F65
For FORD COURIER VAN
from October 1991-

MATERIALS

A	1	Tubular Cross Bar with international facing to ISO 3853 (BS AU114)
C	2	Side Mounting Cleats.
D	2	M10 x 100mm Bolts, Nuts, Lock Washers and Large Flat Washers (40mm O.D.)
D1	2	Bushes (17mm O.D. - 69mm Long)
E	2	M12 x 35mm Bolts, Nuts and Lock Washers
F	2	M10 x 25mm Bolts, Nuts and Lock Washers
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers

FITTING

1. Each side undo the main bumper mounting bolts and loosely attach Side Mountings (C) with existing bolts at (X). On later models where exhaust bracket is mounted on left on Bolts (X) remount to lower holes provided in Side Mounting (C) using Bolts (F).
2. Lower the spare wheel and find the two holes provided in the frame at (D). Drill through the back panel 10.5mm. Insert Bushes (D1) into the frame and loosely attach Cross Bar (A) with Bolts (D) using the large washers on the outside of the panel.
3. Attach the Cross Bar to the Side Cleats with Bolts (E) and finally tighten all bolts.

Note: If necessary the exhaust may be lowered a little by a small amount of bending the upper hanger.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

