



Fitting Instructions

TOWBAR: -
For RENAULT TRAFIC / VAUXHALL RN112A
VIVARO (2014-) / NISSAN NV300 (2016-)
FIAT TALENTO (2016-)

MATERIALS

A	1	Crossbar
B	2	Sidearm
C	1	Left Hand Sidearm
D	1	Right Hand Sidearm
E	6	M10 x 40 x 1.5mm Bolts, Lock Washers and Large Flat Washers
F	6	M14 x 40 x 1.5mm Bolts, Lock Washers and Large Flat Washers
G	8	M14 x 35 x 1.5mm Bolts & Nyloc Nuts
CB	2	M16 x 60 Coupling Bolts, Lock Washers & Nuts
ZE	1	ZEP35 Electric Plate (not shown)

FITTING

1. Ensure mounting points in the chassis are clean and free from dirt and underseal.
2. Loosely attach the Crossbar (A) to the vehicle using fixings:-
(E) for vehicles pre 2014
(F) for vehicles 2014 on
3. Loosely assemble the Sidearms (B & C) and (B & D) as shown using fixings (G)
4. Loosely attach the assembled Sidearms to the Crossbar (A) using the remaining fixings (G)
5. Loosely attach the assembled Sidearms to the vehicle chassis using the remaining fixings of:-
(E) for vehicles pre 2014
(F) for vehicles 2014 on
6. Check the alignment of the Crossbar (A) then fully tighten all bolts to their recommended torque settings

Note: This towbar must be used with either a Witter Towball (part number Z11) or Class A50-1 or A50-X/S towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar, also Z46 Universal Coupling & Z52B. Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

