

# FITTING INSTRUCTION

**RV2007A**  
Batch 000000

**Range Rover 1970-1994 (& Classic 1994-1996) & Discovery 1989-1998**  
NOTE: THIS TOWBAR MUST NOT BE FITTED TO ANY LIGHT PASSENGER VEHICLE REGISTERED ON OR AFTER AUGUST 1ST 1998

## COMPONENTS

ITEM	QTY	DESCRIPTION
A	1	Towbar
B	2	Side Arms LH & RH

## BOLT PACK

ITEM	QTY	DESCRIPTION
C	2	M16 x 50 Bolts, Nuts & Washers
D	2	M12 x 100 Bolts & Washers
E	2	M12 x 30 Bolts, Nuts & Washers
F	2	M10 x 110 Bolts, Nuts & Washers

## FITTING PROCEDURE

- ⇒ Locate the two holes in rear crossmember then slide towbar (A) between bumper and above the crossmember and attach with bolts (D) ( on some models it may be necessary to remove the bumper to attach towbar A )
- ⇒ Undo the bolts securing the towing eyes and attach side arms (B) to these mounting points with bolts (F) and to towbar A with bolts (E)

### TIGHTEN ALL BOLTS

TORQUE SETTINGS ISO Coarse Pitch M8=29Nm, M10=58Nm, M12=102Nm, M16=252Nm  
ISO Fine Pitch M8=31Nm, M10=61Nm, M12=111Nm

**THE VEHICLE MANUFACTURER'S SPECIFICATION FOR THE TRAILER WEIGHT AND NOSE LOAD LIMITS MUST BE OBSERVED.**

## FITTING DIAGRAM

