



Fitting Instructions

TOWBAR HN52A
For Honda HRV
(Jan 2002-)

MATERIALS

A	1	Towbar Main Frame with European facing to 94/20/EC A50-1
C	1	Side Arm Left Hand
D	1	Side Arm Right Hand
E	1	Cleat Left Hand
F	1	Cleat Right Hand
G	2	Spreader Plates with Captive Threads
H	4	M12 x 30 x 1.75mm Bolts and Lock Washers
J	4	M12 x 30 x 1.75mm Bolts, Nuts and Lock Washers
K	2	M12 x 30 x 1.75mm Bolts, Nuts and Lock Washers
M	2	M16 x 65 x 2.00mm Bolts, Nuts and Lock Washers
CB	2	M16 x 50mm Coupling Bolts, Nuts and Lock Washers
BC	4	M16 Bolt Caps
Q	2	Blanking Grommets
Z	1	ZEP35 Electrical plate (not shown)

FITTING

1. Remove the bumper (6 bolts along the top edge, 8 plastic plugs on the lower edge, 2 tips screws and 4 mud guard screws in the wheel arch's. Remove the plastic under trim (2 plastic plugs in the mudguard, 1 plastic forward plug R.H. side, and 2 bolts forward L.H. side. Cut to enlarge the towing eye slot as shown.
2. Remove the metal cans on the rear panel and enlarge hole to 30mm I.D. to insert Spreader Plates (G) into the chassis.
3. Loosely attach Side Arms (C and D) to Spreader Plates (G) using Bolts (H).
4. Loosely attach Main Frame (A) to Side Arms (C and D) using Bolts (J) and to vehicle towing eye using Bolts (M).
5. Loosely attach Cleats (E and F) to Side Arms (C and D) using Bolts (K) and to the captive stud on the vehicle rear panel using original nuts (X). Tighten all bolts.
6. Insert Blanking Grommet (Q) into 30mm hole. Replace plastic under trim and bumper.

Note: This towbar must be used with either a Witter Towball (part number Z1) or Class A50-1 or A50-X towball dimensionally conforming to A50-1 with a 'D' and 'S' value greater than or equal to that of the towbar.

Please refer to the vehicle specification for the trailer weight and nose limits, which **must be observed**.

Recommended torque settings: M8 - 27Nm, M10 - 53 Nm, M12 - 95 Nm, M14 - 150 Nm, M16 - 214 Nm

